

**HANGAR 9**  
**FS One™**  
 Precision RC Flight Simulator



**Key Command Card**

**Simulation Control**

Quit/Exit ..... Esc  
 Pause ..... P  
 Reset ..... Space  
 InstantUp ..... U

**Help**

HelpOverlay ..... /

**Wind**

Increase Wind Speed ..... Home  
 Decrease Wind Speed ..... End  
 Rotate Wind Direction Left ..... -  
 Rotate Wind Direction Right ..... =

**Flight Recorder**

Record Flight On/Off ..... Enter  
 Flight Recorder Playback Tool ..... Backspace

**Sound**

Quiet Sound ..... Q

**Just for Fun**

Aerials ..... Keypad 1

**Views**

Primary View ..... F1  
 Secondary View ..... F2  
 Pilot Views ..... F3

Field Views ..... F4  
 Leashed Views ..... F5  
 Chase Views ..... F6  
 Mouseable Chase Views ..... F7  
 Onboard Views ..... F8  
 Padlock Views ..... F9  
 Reverse Padlock Views ..... F10  
 FlyBy Views ..... F11  
 Misc Views ..... F12

**View Controls**

Auto/Manual Zoom ..... A  
 Default Manual Zoom ..... D  
 Zoom In ..... Z  
 Zoom Out ..... X  
 Increase View Distance ..... N  
 Decrease View Distance ..... B  
 Next Padlock ..... PageUp  
 Prev Padlock ..... PageDn  
 EyePt Position Up ..... Keypad \*  
 EyePt Position Down ..... Keypad 3  
 Walk Forward ..... Arrow Up  
 Walk Backward ..... Arrow Down  
 Walk Left ..... Arrow Left  
 Walk Right ..... Arrow Right

**Trims**

Left Roll Fine Trim ..... Keypad 7  
 Right Roll Fine Trim ..... Keypad 9

Left Yaw Fine Trim ..... Keypad 4  
 Right Yaw Fine Trim ..... Keypad 6  
 Pitch Up Fine Trim ..... Keypad 5  
 Pitch Down Fine Trim ..... Keypad 8

**Play 2 Control**

Player 2 Control ..... Shift

**Tx Overdrive Recordings**

Start Recording ..... [  
 Stop Recording ..... Keypad 0  
 Save Recording ..... ]  
 Save Initial Conditions ..... \  
 Start Playback ..... ,  
 Stop Playback ..... .

**Save Position to File**

Save Position to File ..... ' ,

**Sailplane/Glider Controls**

Hand Launch ..... Space  
 Towline Disconnect ..... Insert  
 Winch Tension ..... `

**Supplemental Aircraft Controls**

Smoke ..... S  
 Start Engine ..... J  
 Kill Engine ..... K  
 Fire Weapon ..... Left Ctrl  
 Cycle Weapons ..... Left Alt

**Supplemental Tx Controls**

Flight Mode Key ..... 1  
 Flight Mode Key ..... 2  
 Flight Mode Key ..... 3  
 Flight Mode Key ..... 4  
 Flight Mode Key ..... 5  
 Custom Mapped Key ..... 6  
 Custom Mapped Key ..... 7  
 Custom Mapped Key ..... 8  
 Custom Mapped Key ..... 9  
 Custom Mapped Key ..... 0

**Widgets and Tools**

Wind Compass ..... W  
 Magnetic Compass ..... C  
 Example Tx ..... E  
 Radar Gun ..... R  
 Timer/Clock ..... T  
 Inset Window ..... I  
 Frame Rate ..... F  
 Sky Grid ..... G  
 HUD ..... H  
 Landing Distance ..... L  
 Variometer ..... V  
 Map ..... M

[www.fsone.com](http://www.fsone.com)

**3D ONLY**

Quit/Exit Esc	Primary View F1	Secondary View F2	Pilot Views F3	Field Views F4	Leashed Views F5	Chase Views F6	Mouseable Chase Views F7	Onboard Views F8	Padlock Views F9	Reverse Padlock Views F10	FlyBy Views F11	Misc. Views F12	
Winch Tension ,	Flight Mode Key 1	Flight Mode Key 2	Flight Mode Key 3	Flight Mode Key 4	Flight Mode Key 5	Custom Mapped Key 6	Custom Mapped Key 7	Custom Mapped Key 8	Custom Mapped Key 9	Custom Mapped Key 0	Rotate Wind Direction - Left [	Rotate Wind Direction = Right =	Flight Recorder Playback Tool Backspace
Cycle Through Aircraft to View Tab	Quiet Sound Q	Wind Compass W	Example Transmitter E	Radar Gun R	Timer Clock T		Instant Up U	Inset Window I		Pause P	Start Recording TxOverdrive [	Save Recording TxOverdrive ]	Save Initial Conditions \
Caps Lock	Auto Manual Zoom A	Smoke S	Default Manual Zoom D	Frame Rate F	Sky Grid G	HUD H	Start Engine J	Kill Engine K	Landing Distance L		Save Position to File ,	Record Flight On/Off Enter	
Player 2 Control (Hold Down) Shift	Zoom In Z	Zoom Out X	Magnetic Compass C	Variometer V	Decrease View Distance B	Increase View Distance N	Map M	Start Playback TxOverdrive ,	Stop Playback TxOverdrive .	Help Overlay /	Player 2 Control (Hold Down) Shift		
Fire Weapon Ctrl	Win/Opt	Cycle Weapons Alt	RESET (or Hand Launch) Space					Alt	Option	Ctrl			

Prt Screen	Scroll Lock	Pause Break
Towline Disconnect Insert	Increase Wind Speed Home	Next Padlock Pg Up
Delete	Decrease Wind Speed End	Previous Padlock Pg Dn
Walk Forward Up	Walk Left Left	Walk Backward Down
	Walk Right Right	



[www.fsone.com](http://www.fsone.com)

Num Lock	/	Eye Pt Position Up *	-
Left Roll Fine Trim 7	Pitch Down Fine Trim 8	Right Roll Fine Trim 9	
Left Yaw Fine Trim 4	Pitch Up Fine Trim 5	Right Yaw Fine Trim 6	+
Aerials 1		Eye Pt Position Down 3	
Stop Recording TxOverdrive 0	.	Enter	